

-4%

-2%

33.33 RPM

+2%

+4%

-4%

-2%

78.26 RPM

+2%

+4%

www.SoundsClassic.Com
STROBOSCOPE DISC

33 $\frac{1}{3}$ RPM

78 RPM

OPERATING INSTRUCTIONS

Use a razor blade to carefully cut an X into the center hole. Place the Stroboscope disk on the Turntable platter - Cue the tone arm up so needle will not touch disk. Set appropriate speed and turn on turntable. View under fluorescent light. Note carefully which row of dots appears to be standing still. If speed is fast or slow, adjust so the large center row of dots, marked with the RPM designation, appear to be still.